



Note

- 1: All dimensions are written in inches. () shows millimeters.
- 2: When you implant wirings into the wall, arrange an electric parts box at your end and implant it.
- 3: When installing the remote controller to an electric parts box, use the accompanying machine screws (M4×25).
- 4: For remote control wiring, shield wire, AWG18-16 needs to be arranged at your end, then crimp connect with the wire from the remote controller by using accompanying wire joint.

ORDER NO. _____					PMAC
PROJECT NAME _____					
INQUIRY FROM _____					
DESIGNED BY	CHECKED BY	APPROVED BY	DATE	SCALE	NAME Slimline remote controller
				Not to scale	Dimensions
					DRAWING NUMBER 43-07-080